



74LBTFSS - LD24 - DS



74ABTFSS - C20 - ML



74LKNSSC - D20 - SP



74LKNSSC - C22 - RB



74LBSTAS - TQ22 - PFS



74LBSTAS - C20 - PFS



74LKNSSC - HC22 - RB



74LBTTAS - C24 - PFS



74LBSTAS - C24 - PFS


Style

- 1 **L** Loose Back **A** Attached Back

- 2 **Backs** **KN** Knife Edge **BT** Box Tee **BS** Box Straight



- 3 **Arms** **TA** Track Arm **FS** Full Sock **SC** Scoop



Size



4


	LD Sofa	D Sofa	TQ Sofa	LS Love Seat	HC* Chair & 1/2	C Chair
Track Arm	W: 80	74	69	57	44 ^{1/2}	34 ^{1/2}
Full Sock	W: 86	80	75	63	50 ^{1/2}	40 ^{1/2}
Scoop	W: 85	79	74	62	49 ^{1/2}	39 ^{1/2}

*All sofas come with 1 pair of #20 pillows except HC has 1 pair of smaller #13 pillows.

Seat Depths



Base



LD and D sofas have a center leg for SP, LSP and DS bases only.