





Manchester Sectional



1195-2L Left Arm Facing Loveseat
1195-2R Right Arm Facing Loveseat

outside H 37.5 W 58 D 38 | inside H 18 W 46 D 23 in.
seat H 20 in. | arm H 25 in.



1195-AL Armless Loveseat


outside H 37.5 W 46 D 38 in. | inside H 18 W 46 D 23 in.
seat H 20 in.

1195-AC Armless Chair

outside H 37.5 W 23 D 38 in. | inside H 18 W 23 D 23 in.
seat H 20 in.


1195-SC Square Corner

outside H 37.5 W 38 D 38 in. | inside H 18 W 23 D 23 in.
seat H 20 in.




1195-AS Armless Sofa

outside H 37.5 W 69 D 38 in. | inside H 18 W 69 D 23 in.
seat H 20 in.




1195-1L Left Arm Facing Chair
1195-1R Right Arm Facing Chair

outside H 37 W 34 D 38 in. | inside H 18.5 W 23 D 23 in.
seat H 20.5 in. | arm H 25 in.




1195-3L Left Arm Facing Sofa | 1195-3L-S Left Arm Facing Sleeper Sofa
1195-3R Right Arm Facing Sofa | 1195-3R-S Right Arm Facing Sleeper Sofa

outside H 37.5 W 81 D 38 in. | inside H 18 W 69 D 23 in.
seat H 20 in. | arm H 25 in.




1195-LCH Left Arm Facing Chaise
1195-RCH Right Arm Facing Chaise

outside H 37.5 W 34 D 62.5 in. | inside H 18 W 23 D 46 in.
seat H 20 in. | arm H 25 in.



1195-3LAC Left Arm Facing Corner Sofa
1195-3RAC Right Arm Facing Corner Sofa

outside H 37.5 W 95 D 38 in. | inside H 18 W 69 D 23 in.
seat H 20 in. | arm H 25 in.



1195-RC Round Corner

outside H 37.5 W 47 D 38 in. | inside H 18 W 36 in.
seat H 19 in.

photographed above: 1195-3LAC, 1195-2R